

Channel	Function	Scale	Detail
1	DIMMER	0→255	Dimmer 0→100%
2	RED	0→255	Red 0→100%
3	GREEN	0→255	Green 0→100%
4	BLUE	0→255	Blue 0→100%
5	STROBE	0→255	Strobe Slow To Fast 0→100%
6	MACRO	0→ 19	Color 1
		20→39	Color 2
		40→59	Color 3
		60→79	Color 4
		80→99	Color 5
		100→119	Color 6
		120→127	Color 7
		128→169	R B Slow To Fast
		170→210	Colors Change Slow To Fast
		211→255	Colors Fade Slow To Fast