



24 PCS RGBWA+UV 6 IN 1 Waterproof Par Light



User manual

Products brief introduction:

- Input Power: AC90 ~ 240V 50/60Hz
- Power:200W
- Light source:24*10W 6 in 1 LED
- DMX Channel: 10CH/6CH
- Control mode: Sound, Auto, Master and DMX 512
- Protection level:IP65

DMX512 Channel:

10CH:

- Channel 1.....Dimmer. Red, green, blue, white, amber and UV are dimmed from dark to bright
- Channel 2R dimmer. from dark to bright
- Channel 3.....G dimmer. from dark to light

- Channel 4.....B dimmer. from dark to light
- Channel 5.....W dimmer. from dark to light
- Channel 6.....A dimmer. from dark to bright
- Channel 7.....UV dimmer. from dark to light
- Channel 8.....Strobe. R、 G、 B、 W、 A、 UV strobe, from slow to fast
- Channel 9.....Function. 0----50: DMX dimmer ; 51----100: color out (8);
101----150: Jump; 151—200: gradual change;
201—250 Pulse variable; 251-255:voice
- Channel 10.....Function speed. Function speed, from slow to fast
(color is selected when output)

6CH:

- Channel 1..... R dimmer. Red dimmer, from dark to bright
- Channel 2..... G dimmer. Green dimmer, from dark to light
- Channel 3..... B dimmer. Blue dimmer, from dark to light
- Channel 4..... W dimmer. White dimmer, from dark to light
- Channel 5..... A dimmer. Amber tinted light, from dark to bright
- Channel 6..... UV dimmer. Purple dimmer, from dark to light

The digital tube displays the menu description

No.	Content	Value	Function and Description
1	d001	001- 512	DMX512 address code sets -10 channel mode
2	A001	001- 512	DMX512 address code sets the -6 channel mode
3	R255	000 - 255	Red dimmer, from dark to bright
4	G255	000 - 255	Green dimmer, from dark to light
5	B255	000 - 255	Blue dimmer, from dark to light
6	U255	000 - 255	White dimmer, from dark to light
7	Y255	000 - 255	Amber tinted light, from dark to bright
8	A256	1 - 255	UV dimmer, from dark to light
9	FH99	01 - 99	R、 G、 B、 W、 A、 UV strobe, from slow to fast
10	CL01	01 - 99	8 colors output.
11	CC01	01 - 99	Colorful jump, from slow to fast.
12	DE99	01 - 99	Colorful gradient, from slow to fast.
13	CP99	01 - 99	The colorful pulse changes from slow to fast.
14	SU01	01 - 99	Mode: 1-8 is 7 color strobe, 9 is 7 color jump