

<b>CHANNEL</b>	<b>FUNCTION</b>
1	PAN
2	TILT
3	FINE PAN
4	FINE TILT
5	PAN/TILT SPEED
6	FROST
7	STROBE
8	SHUTTER
9	COLOUR
10	LAMP ON
11	GOBO
12	SHAKE GOBO
13	ZOOM
14	PRISMA
15	PRISMA ROTATION
16	RESET