

## Digital Par lamp specification



### 1: Display panel operation

Boot press MANU to enter the main menu, press UP (on) DOWN (lower) select sub menu, and then press ENTER to determine

d001	⇒	d512	⇒	7CH mode
CC01	⇒	CC99	⇒	Stochastic model
CP01	⇒	CP99	⇒	Pulse variable
DE01	⇒	DE99	⇒	Demo mode
BE0E	⇒	BE0E	⇒	Audio Mode
R001	⇒	R255	⇒	Red dark - bright
G001	⇒	G255	⇒	Green dark - light
B001	⇒	B255	⇒	Blue dark bright

### DMX512

passageway	Channel value	Function description
CH1	0-255	Total dimming
CH2	0-255	Strobe
CH3	0-255	Voice
CH4	0-255	speed
CH5	0-255	Red light
CH6	0-255	Green dimming
CH7	0-255	Blue light