


USER MANUAL

LCD display:



Menu Enter Up Down

LCD SYSTEM MENU

NO	Values			Function
1	Automatic	Yes		AUTO MODE:ON/OFF
		No		
2	Sound	Yes		SOUND CONTROL MODE:ON/OFF
		No		
3	DMX512	Yes		DMX MODE:ON/OFF
		No		
		Address 001		DMX ADDRESS 001-255
4	Speed	1-9		Speed Adjustment
5	Program	1-15	Yes	Built-in program:ON/OFF
			No	
6	Version	V1.2LED-1024		Software version

DMX TRAITS

Channers	DMX Values	Function
1	000-255	Master Dimming
2	000-255	Strobe: Slow to fast
3	000-255	Red Dimming
4	000-255	Green Dimming
5	000-255	Blue Dimming
6	000-255	Built-in program 1-15
7	000-255	Built-in program 16-30(NO Function)
8	000-255	Speed Adjustment slow to fast

